(Always refer to the current catalogue for complete application listings)

N.B: This installation guide should be used in conjunction with the workshop manual.

FIGURE 1





FIGURE 2

✓ Using a suitable support stand hold the front of the differential housing up to allow removal of the front vertical mount bolts as shown below. Remove both bolts as indicated in the above image.



(Always refer to the current catalogue for complete application listings)

N.B: This installation guide should be used in conjunction with the workshop manual.

FIGURE 3

Once the bolts have been removed lower the stand approximately half an inch to allow removal of the front upper OEM washer.





FIGURE 4

Lubricate the upper insert ring with the grease supplied in the kit. When installed correctly the ring requires stretching over the top of the OEM differential mount to seat correctly. Carry out this procedure for both sides.
Note: Large flange face is installed upward.



(Always refer to the current catalogue for complete application listings)

N.B: This installation guide should be used in conjunction with the workshop manual.

FIGURE 5





FIGURE 6

Re-fit the OEM washer to the top side of the bushing ensuring the contact faces are well lubricated.



(Always refer to the current catalogue for complete application listings)

N.B: This installation guide should be used in conjunction with the workshop manual.

FIGURE 7

- $\ensuremath{\mathscr{D}}$ Fit the supplied lower insert onto the OEM lower washer and lubricate all contact faces.
- Note: Ensure locating tabs are engaged into the OEM slots.





FIGURE 8



(Always refer to the current catalogue for complete application listings)

N.B: This installation guide should be used in conjunction with the workshop manual.

FIGURE 9

Correct installation of the supplied lower insert into the OEM rubber bushing.




FIGURE 10

- Note: Slight interference crush on the upper insert seat will be noted after tensioning.



(Always refer to the current catalogue for complete application listings)

N.B: This installation guide should be used in conjunction with the workshop manual.

FIGURE 11





FIGURE 12

- ${\ensuremath{\mathscr{P}}}$ Remove the rear swaybar mounting bracket bolts from both sides to enable correct access and full removal of the OEM rear differential bolts.
- Note: Rear swaybar does not need to be fully removed from the vehicle.



(Always refer to the current catalogue for complete application listings)

N.B: This installation guide should be used in conjunction with the workshop manual.

FIGURE 13

Remove the bolts as per indicated in the image below.





FIGURE 14

Taking note of the flat washer supplied in the kit a slight elongation is observed to allow for correct fitment and alignment to the differential holes. The elongated hole is installed to the top of the two bolt differential mount.



(Always refer to the current catalogue for complete application listings)

N.B: This installation guide should be used in conjunction with the workshop manual.

FIGURE 15

✓ Install the two supplied rear differential inserts into the OEM differential bushings ensuring they are well lubricated. The insert with the voided holes installs into the right hand side with the supplied stepped washer ✓ Note: Orientation of the voiding is symmetrical.




FIGURE 16

Tension all bolts to OEM specification and re-fit swaybar mounting saddles.

