

**Subaru 08-09 Legacy GT, Spec B & Outback XT
 AVO Grill v2 Installation Guide
 PN# S1108M8GB001T**

You are now the proud owner of a highly tested and proven AVOTurboworld Front Grill kit. While you have made a wise choice in selecting this body part, below we have some suggestions and procedures for you to follow in ensuring its successful installation.






Tools Required

- Screwdriver Set
- Metric Socket Set
- Wire cutters

Kitting List

Note: Check this kit list before starting the install to make that you have all these parts.

		
1 x Grill Surround	1 x 40mm Wire	1 x Grill Mesh

A) Orientation

Before grabbing a bunch of spanners and attacking your car take a moment to **STOP AND THINK**

Read these supplied installation instructions thoroughly from start to finish – do you understand all of the mechanical operations required? Are you sure that you can adequately complete all of the mechanical operations required?

Installation

ALLOW THE VEHICLE TO COOL DOWN BEFORE STARTING WORK.



Remove the factory front grill from the car. There is two main pop-its holding the grill at the top, and small screws holding the grill from the back. The pop-it is easily removed with a small, flat-head screwdriver. The screws in the back need to be reached from behind. You may need to remove the two pop-its holding the bumper down (see arrow).



Finally, there are four clips at the top rear of the grill fastening it to the frame. These are easily removed with a small screwdriver. Simply insert the head of the screwdriver into the hole at the top of the grill.



And press down on the tab inside the hole to slide the grill off. After the grill has been removed, remove these four mounts from the car, as they are no longer required. To remove them, push down on the small tab at the top near the body.



Assemble the AVO grill. There should be three separate pieces – the grill surround, the grill mesh, and 40mm of wire.



Attach the mesh to the grill surround with the supplied wire. This mesh may require some minor trimming to fit. Bend the edges of the mesh over the side and fasten it tightly with the supplied wire. The wire needs to be cut into several pieces, one for each mount point.



Once you have assembled the grill to your satisfaction, install it on the car. Insert the pop-its in the top opening on either side. You may need to place a bit of foam padding between the bumper skin and bumper beam to get the bumper to match up correctly at the bottom.

Job Done-Enjoy your car!

NOTE! – If in any doubt over the operation or installation of your parts, contact AVOTurboworld or the official AVO distributor that you purchased this part from.