

# Fitting Instructions #TRC2924IS

Subaru Impreza GD, GG

## Front Swaybar Link Rod Kit

- With the vehicle at normal ride height, remove the original front Swaybar link rod. Note: Do not jack the body, use a drive-on ramp or similar for easy access;
- Clean the contact area on the lower control arm and the Swaybar.
- Apply the grease supplied to all mating surfaces with the front Swaybar link and then, install the new front Swaybar link with all supplied hardware as depicted in the diagram below.
- Tighten all fasteners to manufacturer's torque specification and road test the vehicle.
- Do a safety check on the front Swaybar link after travelling 1000kms;

