



0%, 2%, 3% and 4% Oversized Lightened Crank Pulley

2013-07-22

Thank you for purchasing this ALTA product for your car! Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation. We can be reached in any of the following methods:

Email Tech@ALTApformance.com
Instant Chat off the main page of www.ALTAperformance.com
Or simply call our tech team at 503-693-1702

NOTE: THE LARGER SIZE PULLEYS ARE DESIGNED FOR "OFF-ROAD" USE ONLY! CHECK WITH FEDERAL AND LOCAL AUTHORITIES PRIOR TO INSTALLATION. ALTA PERFORMANCE IS NOT RESPONSIBLE FOR REPAIRS NECESSARY AS A RESULT OF MIS-INSTALLATION OR DAMAGE OF SUPERCHARGER OR ENGINE.

- 1) Remove factory crank pulley using factory approved methods and factory available puller. Clean exposed crankshaft of any grease or oil.
- 2) ALTA crank pulley is installed identically to the factory part. Press onto the crankshaft using factory installation kit and tighten bolt to 84.8ft-lbs. **Option:** Heating pulley in an oven to 300 degrees F, will allow pulley to slide on to nose of crank with ease. This method requires the pulley to be heated then **immediately** installed with no delay. If this method is used for installation, use proper hand protection.
- 3) Before installing serpentine belt, determine what belt is needed using serpentine belt pulley matrix. The numbers supplied are NAPA part numbers and can be cross-referenced to other manufacturers.
- 4) Install belt using factory tensioner and continue to follow factory service manual.

CRANK PULLEY SIZE

SUPERCHARGER PULLEY SIZE	+5% Supercharger Pulley for Twurbo kit uses #060547	Stock Crank Pulley	2% Oversized	3% Oversized	4% Oversized
	Stock Supercharger Pulley	Stock belt	Stock belt	NAPA Belt #060547	NAPA Belt #060547
	15% Supercharger Pulley	NAPA Belt #060535	NAPA Belt #060539	Stock belt	Stock belt
	17% Supercharger Pulley	NAPA Belt #060535	NAPA Belt #060539	NAPA Belt #060539	Stock belt

NOTE: Squealing of the belt is not normal. Incorrect belt size or a faulty belt tensioner generally causes this. Re-check belt and belt tensioner for defects. If car came equipped with correct size belt and belt has more than 15K miles, a NEW serpentine belt is highly recommended.

NOTE: OVERSIZED CRANK PULLEY CUSTOMERS WILL NOTICE A HIGHER LEVEL OF ENGINE NOISE AND SUPERCHARGER WHINE. THIS IS A NORMAL BYPRODUCT OF PULLEY INSTALLATION AS THE SUPERCHARGER IS SPINNING AT A HIGHER RATE OF SPEED. AS WITH ALL HIGH PERFORMANCE MODIFICATIONS USE OF PREMIUM FUEL IS REQUIRED WITH THESE PULLEYS.

ALTA SPECIAL NOTE:

Please treat the larger crank pulleys like a smaller SC. The ultimate SC pulley size can be calculated by using this formula:

SuperChargerSize+CrankPulleySize=Desired SC pulley size

Example: 15% reduction SC pulley+ 3% overdrive crank pulley=18% supercharger pulley reduction.

When crank pulley/supercharger pulley combo adds up to 17% or more, the factory redline of the engine must not be exceeded. This is important for long SC life. Any increase in supercharger speed beyond 17% total reduction will lessen the useful life of the supercharger.

Questions, Comments and Suggestions Contact: Tech@ALTApformance.com
Visit Our Website for Instant Chat Options at <http://www.ALTAperformance.com>

Call Our Tech Team at 503-693-1702